

MONTAGEHINWEIS

INSTALLATION NOTE

AEA

Downlight




STENG LICHT AG | Hedelfinger Strasse 103 | D- 70327 Stuttgart
Phone +49- 711- 23 88 00 | Fax +49- 711- 23 88 088
mail@steng.de | www.steng.de

DEUTSCH

Einbauöffnung lt. Angaben exakt bohren,
12V- Zuleitung bzw. Trafo anschließen, Feder
mit Fingern zusammendrücken und Downlight
einsetzen.

Zum Schluss das Leuchtmittel einsetzen.


Technische Daten:



ENGLISH

- Cut out exact like the drawing
- Connect downlight to 12V cable or mount transformer
- Insert downlight in the cut-out
- Insert lamp bulb

Technical Data:



Installation der Leuchte

Vor Montage der Leuchte Strom abschalten. Die Leuchte darf
nur durch qualifiziertes Fachpersonal (Elektriker)
angeschlossen werden. Die Leuchte darf nur in trockenen
Innenräumen eingesetzt werden.

Installation of the fixture

To avoid the possibility of electric shock, turn off power-supply
before installing or serving and read all instructions before
installing the fixture. It is recommended that the fixture is
installed only by a qualified electrician. The fixture is suitable
only for normal dry rooms.

⇒ Einbaudurchmesser

Der Einbaudurchmesser
beträgt 35- 38mm !

⇒ Cut-out

The cut-out is 35- 38mm /
1,37inch- 1,47inch !

